




Installation Steps



1. Disassemble all parts of the drainer according to the figure.



2. Use the screw of drainer to connect the parts according to the figure.



If you need to clean the waste, turn the cover counterclockwise and pull it out. After cleaning, reinstall the cover.

Maintenance

(1) To keep the surface of the click plug bright and clean, please clean regularly.

1. Clean with water frequently with Soft cotton cloth, colorless glass cleaner, do not have grind action.

2. Do not use acidic detergents, which can erode surface coatings.

3. Do not use cleaning powder or polishing powder containing coarse particles of detergent or nylon brush, in order to avoid wearing out products.